



10ft8in Wide x 20ft Deep x
6ft8in Side Height / 9ft6in Center Height



Item #: TS1020E6












With 6 Legs and cover

Distributed by:
YJ(USA)Corp.,
3970 Lindbergh Drive Addison,
1-877-927-8777 www.jumpking.com
9.00am ~ 5.00pm CST
Monday thru Friday

WARNING!

Keep all flame and heat sources away from the tent fabric. The fabric is not fire proof. The fabric will burn if left in continuous contact with any flame source.


PARTS LIST

1. Bottom leg frame with Pivot Foot (D)	6 pcs	
2. Top leg frame (C)	6 pcs	
3. Middle 4-way connector	3 pcs	
4. Top center 3-way connector	6 pcs	
5. Tilt tube (A)	6 pcs	
6. Tilt tube (B)	6 pcs	
7. Horizontal tube (E)	6 pcs	
8. Horizontal tube (F)	6 pcs	
9. Cover	1 pc	
10. Hex nut screw	6 pcs	
11. Valance tie down	6 pcs	

FRAME ASSEMBLY

Step 1


Separate all pieces according to size and shape and arrange per the illustration shown below.



Step 2

Start with the center and complete the center frame first. Then assemble each side.

NOTE: Attach the cover with Top leg frame(C) before inserting the Bottom leg frame with Pivot Foot(D)



Start Here

DO NOT CONNECT LEG POLES AT THIS POINT!

COVER ASSEMBLY

Step 1

Unfold the cover with Black webbings facing downward and place over the frame. The flared edges should be located at each of the 4 corners of the frame.

Step 2


Begin attaching the cover with the elastic hook straps by inserting the elastic cord underneath the cover and through the black webbing. Then pull the cord creating the loop. Last insert hook end through the loop the pull until tight.



LEGS ASSEMBLY


NOW, CONNECT THE LEG POLES TO THE ROOF ASSEMBLY WITH THE COVER ALREADY POSITIONED ON TOP OF THE UNIT.

Step A: First insert the Top leg frame(C) into the Corner 3-way connector, Corner 3-way connector, and Middle 4-way connector. Then connect the Bottom leg frame with Pivot Foot (D) in the same way. (See illustration).




Step B: Connect the hook down to the Top leg frame(C) of each leg.

- a. Start by attaching Elastic hook at four corners.
- b. Continue attaching from center on both side of canopy.



IMPORTANT! Once the legs and cover are assembled, your canopy will be prone to wind damage. It is imperative that the canopy anchors be installed NOW!

FINISH ASSEMBLY OF YOUR CANOPY



IMPORTANT NOTICE: PLEASE READ CAREFULLY

We are confident that you will be completely satisfied with your Canopy unit. Please take a moment to read the very important information below, and call us with any questions you may have.

YJ(USA)Corp., has no control over wind, snow, ice, rain or any other weather condition and we are in no way responsible for any damage caused by the canopy or to the canopy. We suggest you contact your insurance carrier just as you would for any other outside structure.

OTHER PRECAUTIONS WHICH MUST BE FOLLOWED:

Keep all flame and heat sources away from the tent fabric. The tent fabric will burn if left in continuous contact with any flame source.

DO NOT cook underneath or near canopy.

DO NOT store or use flammable liquids underneath or near canopy.

DO NOT ignite or store fireworks underneath or near canopy.

DO NOT use bleach to clean cover.

DO NOT dry clean cover.

DO NOT wash cover in washing machine or dry in dryer. Hand wash with mild soap and water only.

DO NOT allow rain water, snow or ice to accumulate on top of cover.

DO NOT hang or suspend anything from the frame, grommets, truss system or ball straps of the unit.

REMOVE canopy cover before a storm, or disassemble entire canopy unit if possible.

REMOVE rain water, snow and ice from canopy cover.

This is a temporary structure and is not recommended for use as a permanent structure.

PRODUCT INFORMATION

Defective Parts

We try our best to eliminate any defective parts that are shipped with our products. If, however, you should find a defective part, we will replace – free of charge – any part which is defective. You will need to provide proof of purchase showing date of purchase and provide us with detailed description of the defective component. Your replacement will be shipped by ground shipping, freight prepaid. Next day or express shipping will require freight collect and paid for by you, the consumer. Damages from improper anchoring, strong winds, snow, ice or rain are not considered defects.

Improper Anchoring, Strong Winds, Rain Snow, or Ice

YJ(USA)CORP., does not guarantee these canopies under strong weather conditions.

These canopies are designed to protect against damages caused by sun, rain, tree sap, birds, etc. They are not designed to hold roof loads that accompany snow, ice or heavy rains. If your canopy is not anchored securely, it can be lifted by the wind and will fly away. If your canopy takes flight, we are not responsible for any replacement. If you know strong weather is predicted, remove the cover or take down the canopy unit completely. The cover is designed to be quickly and easily removed.

Warranty

All components of this canopy feature a 1-year limited warranty and are warranted to be free from defects in material and workmanship for a period of 1-year. You must complete and return the enclosed warranty card promptly after purchase. Please retain your proof of purchase receipt; you will be asked to provide this receipt in order to obtain warranty service.

Non-Warranty Replacement Parts

If after expiration of the warranty period, you require replacement parts please contact us at 1-877-927-8777. We stock replacement parts and make them available to you at discounted prices. Our customer service department will be pleased to assist you in any way possible.

Certain regions of the country are extremely hard on covers of any kind. Normal wear and tear is not covered under the warranty, and should be expected.

In order to receive a discounted or free replacement part, you may be asked to return the part, freight prepaid, to our warehouse for inspection before we will send a replacement. You must, in all cases, provide a copy of your receipt showing the date of purchase, model number and price.

For missing parts, replacement parts or any questions:

Please call customer services 1-877-927-8777 from 9:00am~5:00pm CST Monday~Friday

Replacement parts and customer service is also available through our website.
Please visit us at www.jumpking.com