


FUNRING®

TRAMPOLINE ENCLOSURE SYSTEM
by *Jumpking*
SISTEMA CERRADO PARA TRAMPOLIN
por *Jumpking*



PRODUCT MODEL JKFR14, JKFR12
TRAMPOLINE ENCLOSURE SYSTEM
for a 14', 12' DIAMETER XT/TR/WS TRAMPOLINE
PRODUCTO MODELO JKFR14, JKFR12
SISTEMA CERRADO PARA UN XT/TR/WS TRAMPOLIN
DE 14' (4,27m), 12' (3,67) DE DIAMETRO

User's Manual Manual del Usuario

SAFETY, USE, PLACEMENT, ASSEMBLY, CARE, AND MAINTENANCE MATERIALS ENCLOSED.
READ THIS MANUAL AND ALL THE MATERIALS FURNISHED WITH YOUR TRAMPOLINE THOROUGHLY BEFORE
ASSEMBLING. KEEP THIS MANUAL WITH YOUR TRAMPOLINE MANUAL SO YOU CAN REFER TO IT LATER.

FUNRING is designed for users weighing 200 pounds or less.

SE INCLUYEN MATERIALES DE SEGURIDAD, USO, COLOCACION, ENSAMBLADO, CUIDADO Y MANTENIMIENTO.
ANTES DE ENSAMBLAR LEA COMPLETAMENTE ESTE MANUAL Y TODOS LOS MATERIALES PROVISTOS. GUARDE ESTE
MANUAL A MANERA DE REFERIRSE AL MISMO POSTERIORMENTE.

FUNRING está diseñado para usuarios que pesen 90,7 kilos o menos.



WARNING



Do not land on head or neck.
Paralysis or death can result,
even if you land in the middle
of the trampoline mat (bed).
To reduce the chance of
landing on your head or neck,
do not do somersaults (flips).



Only one person at a time on
the trampoline. Not recom-
mended for use by children
under 6 years of age.
Multiple jumpers increase the
chances of loss of control,
collision, and falling
off.
This can result in broken
head, neck, back, or leg.

Table of Contents

Content	Page
Warranty Information	4
Read this Manual Before You Begin	6
FUNRING Safety Information	6
Need for FUNRING Safety	6
Assemble the Enclosure Safely	6
Use the Enclosure Safely	7
Store the Enclosure Safely	7
Place the Trampoline in a Safe Place	7
How to Assemble the Enclosure	12
Before Assembling	12
Assembly Steps	12-14
Disassembly and Storage	15
Care and Maintenance of the Enclosure and Trampoline	15
Special Considerations	15
Wind	15
Moving the Trampoline (and Attached Enclosure) a Short Distance	15
Drawing and Parts List	20
Jumpking Tie Down System - optional accessory	22
Ordering Replacement Parts	22

READ THIS MANUAL

All Jumpking FUNRING trampoline enclosure systems come equipped with important information regarding proper assembly, usage and safety procedures. This information must be read by all supervisors and trampoline users before allowing any person to use a FUNRING installed on a trampoline.

WARRANTY INFORMATION

**Jumpking, Inc.
Limited Trampoline Warranty
GUARANTEE VALID ONLY IN THE U.S.A.**

Jumpking, Inc. (Jumpking) warrants its trampoline accessory products to be free from defects in material and workmanship under normal use and service conditions. The various component parts of the FUNRING trampoline enclosure system are warranted against defects and workmanship as follows:

- A. Metal hardware - one year;
- B. Foam sleeves, plastic parts, suspension straps - 90 days;
- C. Fabric, netting, and sewing - 90 days.

All warranty coverage extends only to the original retail purchaser from the date of purchase. Jumpking's obligation under this Warranty is limited to replacing or repairing, at Jumpking's option, the product at one of its authorized service centers. All products for which a warranty claim is made must be received by Jumpking at one of its authorized service centers, freight prepaid, and accompanied by sufficient proof of purchase. All returns must be preauthorized by Jumpking. Preauthorization may be obtained by calling Jumpking's Customer Service Department at 1-800-322-2211. This Warranty does not extend to any product or damage to a product caused by or attributable to freight damage, abuse, misuse, improper or abnormal usage, or repairs not provided by a Jumpking authorized service center or for products used for commercial or rental purposes. No other Warranty beyond that specifically set forth above is authorized by Jumpking.

JUMPKING IS NOT RESPONSIBLE OR LIABLE FOR INDIRECT, SPECIAL OR CONSEQUENTIAL DAMAGES ARISING OUT OF OR IN CONNECTION WITH THE USE OR PERFORMANCE OF THE PRODUCT OR OTHER DAMAGES WITH RESPECT TO ANY ECONOMIC LOSS, LOSS OF PROPERTY, LOSS OF REVENUE OR PROFITS, LOSS OF ENJOYMENT OR USE, COST OF REMOVAL, INSTALLATION OR OTHER CONSEQUENTIAL DAMAGES. SOME STATES DO NOT ALLOW THE EXCLUSION OR LIMITATION OF INCIDENTAL OR CONSEQUENTIAL DAMAGES. ACCORDINGLY, THE ABOVE LIMITATION MAY NOT APPLY TO YOU.

THE WARRANTY EXTENDED HEREUNDER IS IN LIEU OF ALL OTHER WARRANTIES AND ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE IS LIMITED IN ITS SCOPE AND DURATION TO THE TERMS SET FORTH HEREIN. SOME STATES DO NOT ALLOW LIMITATIONS ON HOW LONG AN IMPLIED WARRANTY LASTS. ACCORDINGLY, THE ABOVE LIMITATION MAY NOT APPLY TO YOU.

This warranty gives you specific legal rights. You may also have other rights which vary from state to state.

Copyright © 02/00 Jumpking, Inc




BEFORE YOU BEGIN

Thank you for selecting a Jumping FUNRING trampoline enclosure system.

The Jumping FUNRING is designed and crafted to provide you and your family with many years of backyard fun.

For your benefit and safety, read this manual carefully before anyone uses this trampoline enclosure system. If you have additional questions, please call our Customer Service Department, toll-free, at **800/322-2211** Monday through Friday, 8 a.m. until 5 p.m. Mountain Time (excluding holidays).

Read the safety information on this page and fill out the attached warranty card. Mail the card to JUMPKING. No postage is required.

 WARNING	
	<p>Do not land on head or neck.</p> <p>Paralysis or death can result, even if you land in the middle of the trampoline mat (bed).</p> <p>To reduce the chance of landing on your head or neck, do not do somersaults (flips).</p>
	<p>Only one person at a time on the trampoline. Not recommended for use by children under 6 years of age.</p> <p>Multiple jumpers increase the chances of loss of control, collision, and falling off.</p> <p>This can result in broken head, neck, back, or leg.</p>

Read all instructions thoroughly before you use this trampoline enclosure system, or before you allow anyone else to use it.

Install this enclosure only on a trampoline that has been assembled correctly as specified by its manufacturer. The trampoline must be in good working order. This trampoline enclosure system, when combined with a properly placed and well-maintained trampoline, will provide a recreational asset to any back yard. **Inspect** the trampoline before each use of the enclosure, and replace any worn, defective, or missing parts.

This trampoline enclosure system is designed to be used by people 200 pounds or under.

Trampoline Enclosure System Safety Information

Need for Trampoline Enclosure System Safety

A trampoline enclosure system is a recreational product.

The following information identifies important safety precautions. Some of these precautions apply to all kinds of enclosures, and some are unique to this trampoline enclosure system. The list is not all-inclusive, because an enclosure can be used in ways that this manual cannot cover completely.

Assemble the Enclosure Safely

Detailed step-by-step instructions in this booklet describe how to assemble the enclosure. Adults, not children, must assemble the enclosure. Wear work gloves to protect your hands from pinch points during assembly. When you assemble the enclosure, the elastically supported, netting suspension system, will be under some tension to keep the proper form of the netting. Keep children away from the trampoline enclosure system while it's being assembled, and don't allow them to play with enclosure parts during assembly.

To prevent pinches and cuts during enclosure use, the frame pad must be installed on the trampoline. (See the trampoline manufacturer's instructions on how to do this.) The frame pad must be installed prior to erecting the enclosure. The frame pad reduces the chance of injury from accidental contact with the springs and frame.

Use the Enclosure Safely

Adult supervision of children

When children use the trampoline enclosure system that has been installed on a trampoline they must be supervised by adults. Young children must be supervised constantly. Adults must pay particular attention to —

- ⌘ The things children bring into the enclosure
- ⌘ Children's activities inside the enclosure
- ⌘ Conditions inside the enclosure when children are using it
- ⌘ The way children get into and out of the enclosure

Additional details of safe enclosure use are described below.

Electrocution hazard associated with the metal frame of trampoline

The frame of the trampoline is made of metal. It is not grounded, and it will conduct electricity. Lights, electric heaters, extension cords, and household electrical appliances are not permitted in or on the trampoline enclosure system.

Hazards associated with the height of the trampoline mat (bed)

A trampoline enclosure that is installed on a trampoline is raised off the ground. This increases the **risk of a fall** when going out the enclosure door or netting opening. Darkness increases the chances of a fall when getting in and out of the enclosure. Do not use the trampoline unless adequate lighting is provided. Young children in particular may have difficulty getting in and out of the enclosure. Help young children to get in and out of the enclosure to reduce their risk of falling.

In addition to presenting a raised surface; the mat (bed) and netting walls of the enclosure system are separate pieces. Enclosure users, particularly young children, are not allowed to leave the enclosure by going out between the trampoline mat (bed) and the enclosure netting walls. Trying to exit in this way poses a **risk of strangulation** from being caught between the trampoline's frame and the enclosure netting wall. Only the door or netting opening of the enclosure is to be used to enter or exit the enclosure.

Hazards associated with animals and sharp and glass objects

To avoid damage to the enclosure and trampoline, do not allow pets or other animals inside the enclosure. Their claws and teeth can damage the netting.

Hazards associated with high winds

All trampoline enclosure systems used outside can be blown about in high winds, and this can potentially injure anyone in their path or inside the enclosure. Both the enclosure and the trampoline can be blown over in high or gusty winds. Under such conditions, take down the enclosure netting, stake the trampoline frame to the ground (see page 9 for details), use the Jumping Tie Down Kit (see page 22), or move the total unit to a sheltered location.

Store the Enclosure Safely

The specific steps for storing the enclosure are presented later in the manual. There are some specific safety precautions to be aware of when storing the enclosure.

Remove the attached pole pieces (poles) as a unit. Separate them on the ground. Avoid pinching your fingers by keeping them out from between pinch points near the bracket assembly when you remove the poles from the frame.

Place the Trampoline in a Safe Place

There must be at least 24 feet (7.3 meters) of clear, open space above the trampoline. Do not place or store anything underneath the trampoline.

To avoid injury, the trampoline must be kept away from objects and possible hazards including electric power wiring, tree limbs, and fences. Do not place the trampoline near any other **recreational devices** or **structures** such as a swimming pool or swing set.

The trampoline must be placed on a **level surface** before use, and the area around the trampoline must always be **well lighted**.

TRAMPOLINE ENCLOSURE SAFETY INSTRUCTIONS



WARNING



Do not land on head or neck.

Paralysis or death can result, even if you land in the middle of the trampoline mat (bed).

To reduce the chance of landing on your head or neck, do not do somersaults (flips).



Only one person at a time on the trampoline. Not recommended for use by children under 6 years of age.

Multiple jumpers increase the chances of loss of control, collision, and falling off.

This can result in broken head, neck, back, or leg.

For the Supervisor

Enforce all of the safety rules and be familiar with the information in the User's Manual to help new users and all users to follow trampoline enclosure and trampoline safety.

All trampoline users must have someone watch them, regardless of the skill or age of the jumper. Secure the trampoline against unauthorized and unsupervised use. Keep objects away that could interfere with the jumper.

This trampoline enclosure system is not recommended for use by children under 6 years of age or any one weighing more than 200 pounds.

Use only when the trampoline mat (bed) is clean and dry. Inspect the trampoline prior to each use and replace any worn or damaged parts. Use only when the enclosure netting has no holes, pole clamps are tightly secured to the poles and the frame, and the netting is properly suspended.

For the Jumper

Do not use the trampoline enclosure system when under the influence of drugs or alcohol

Jumping

Avoid jumping too high or for too long. Always control your jump. Do not try to jump over the netting.

Take turns jumping one at a time, and always have someone watch you.

Do not intentionally rebound off the netting. Do not hang from, kick, cut, or climb on the netting.

Wear clothing free of drawstrings, hooks, loops or anything that could get caught in the netting.

Do not attach anything to the netting that is not a Jumping approved accessory or part of the enclosure system.

Getting on and off

Climb on and off the trampoline at the enclosure door or netting opening. Do not jump on or off. Do not crawl under the netting. Do not use the trampoline as a springboard to other objects.

How to Assemble the Enclosure

Adult assembly is required. Assembly requires a 9/16" socket and ratchet, or box-end wrench. The enclosure can easily be disassembled for storage when it is not being used. Read the assembly instructions before beginning to assemble the trampoline enclosure system.

Before Assembling

The assembly instructions refer to parts by name and by part number. Please refer to page 20 for part descriptions and numbers.

Make sure that all parts listed in the parts list are included with the enclosure system. Refer to page 22 for instructions on how to obtain missing parts.

No tools are provided for assembly. A 9/16" socket and ratchet, or box-end wrench are required to attach two (2) pole support brackets and the enclosure poles to the legs of the trampoline frame.

Wear **work gloves to protect your hands** from pinch points during assembly and disassembly.

Remove any ladders or anything on the trampoline that will hinder assembling the enclosure.

Step 1:


First verify that you have received all the enclosure parts. Use the shipping container to keep all the hardware together. You should have the following pieces: **(see page 20 for details)**. If you do not have the required parts then contact your dealer or JumpKing before proceeding (see page 22 for ordering information).

- 1 - FUNRING net with attached hardware
- 8 - plain poles
- 8 - swedged (one end smaller diameter) poles
- 8 - lower clamps (with pole stop tab)
- 8 - upper clamps (aligns with top rail)
- 8 - blue three foot foam sleeves
- 8 - green three foot foam sleeves
- 4 - blue pole caps
- 4 - green pole caps
- 16 - bolts, lock washers, nuts
- 32 - flat washers
- 8 - thread caps
- 16 - suspension cords
- 16 - snap clips
- 8 - rope sections
- 1 - "sewing needle" tool
- 1 - set of 6 frame warning labels

Put one plain pole, one swedged pole, one upper clamp, and one lower clamp, and one pole sleeve of each color at the base of each trampoline leg.

Step 2:

Install a snap clip on each elastic suspension cord (if **flexible part is on the outside - gently push it to the inside** - see Figure 1). These cords will go over each pole and the snap clip will attach to a "D" ring that will suspend the FUNRING around the trampoline mat (bed). Put two cords by each trampoline leg.



Step 3:

NOTE: The FUNRING is designed for Jumping frames (XT, TR, WS) that have three piece legs. The FUNRING poles should be 6' 3" above the top rail of any trampoline to accommodate the sleeves and pole caps. If you are not using the above frames then place an assembled pole next to a leg - raise it 6' 3" above the top rail - this will then determine how far the bottom of the pole will be off the ground and where to position the bottom clamp.

At each trampoline leg do the following (see Figure 2): place the end of a plain pole on the ground (pole is vertical) next to a trampoline leg. Put the upper clamp around the plain pole and the upper part of the vertical leg piece so the curved portion "snugs up to" trampoline top rail. Install nut; lock washer; flat washer; clamp surface with round hole; flat washer, bolt (see Figure 3) and tighten loosely.

Install the cap nuts only on the bottom clamp

Step 4:

Loosely attach a lower clamp below the joint between the vertical trampoline leg piece and the trampoline center leg piece at each trampoline leg (see Figure 3). The clamp will hang loosely on the pole and leg. Slowly move the plain pole piece up off the ground so it is just below the leg joint. The top clamp will help hold the leg vertical and to the frame. Then move the bottom clamp up so it clamps the bottom of the pole. This clamp is designed to position the plain pole end just below the trampoline leg joint. The bottom of the leg should rest on the clamp tab. Tighten this clamp so it will not move but is still slightly loose.

Then tighten the top clamp and then the bottom clamp. Now install the cap nuts on the bottom clamp. Follow this procedure at each trampoline leg.

Step 5:

You will need a step ladder for the next series of steps. Follow all manufacturers instructions when using the ladder. The step ladder should be in good condition. Another person should steady the step ladder for the person on the ladder.

Add a swedged pole section to each attached pole by sliding it into the bottom pole section (see Figure 4). If there is a slight fit problem you may have to gently tap the top of some poles with a rubber mallet or piece of wood to fully seat the top pole into the bottom pole. Be careful to not break the poles loose from the clamps or to deform the edge of the top pole.




Figure 2




Figure 3




Figure 4

Step 6:

Place the FUNRING netting on the trampoline mat (bed). The entry place ("door") should be positioned where you normally access the trampoline. The "D" rings on the vertical seams should be placed next to each pole. The edge with the orange stripe is the "top side" (see Figure 5). **The foam sleeves and pole caps are two different colors (blue & green). You can mix and match to customize a color scheme. Normally you would have a blue pole followed by a green pole.**

At each pole slide a foam sleeve over the pole. Then place a suspension cord over the pole (see Figure 5) and attach the snap clip to the "D" ring in the middle of the FUNRING netting. The cord will go completely around the pole, between the foam sleeve sections, and then to the "D" ring (you will have to use the ladder to "drop" the strap over the pole).

Add the last foam sleeve at each pole followed by a another suspension cord attached to the adjacent "D" ring on the top of the FUNRING netting. On each pole you should have two (2) foam sleeves and two (2) suspension cords (see Figure 5).

The FUNRING netting is now fully suspended (see Fig. 6).

Step 7:

Attach a pole cap on the top of each pole by sliding it over the top of each pole (see Figure 6). There are two colors of pole caps (mix or match).





Step 8:

Around the base of the FUNRING netting and between each pole the netting needs to be attached to the "V" rings on the edge of the mat (bed) by sewing the netting to the "V" rings with the rope sections. Take a rope section and tie it to a "V" ring at a pole. Attach the needle to the other end. Weave the rope from ring to net (use needle to penetrate the net) until you get to the next pole. Remove the needle and tie that end to a "V" ring. Cut off any excess rope. Repeat this operation between the next set of poles. The strap along the base of the door should be tied to the "V" rings just like the base of the netting. This will firmly attach the bottom of the netting and the door strap to the edge of the mat (bed) (see Fig. 7).

Step 9:

Plastic clips secure the door to "D" rings. Always secure the door when using the trampoline. Always secure the door closed and remove any access aids such as ladders or stools when not using the trampoline.

The final procedure is to read and attach the warning placard to the netting close to the door using the two tie wraps and the warning labels to each pole so they are visible (see Fig. 8).



DISASSEMBLY AND STORAGE

To remove the enclosure from the trampoline

Make sure the enclosure is dry before removing and storing. Reverse the order of the basic assembly process.

The enclosure poles should be removed in one piece by loosening the bottom clamp, holding the pole while loosening and removing the top clamp, pulling the pole up and out of the bottom clamp, and laying the pole on the ground. The poles are long and will want to rotate so use caution as to pole ends and the weight of the pole when removing.

Store the enclosure in a safe, dry location.

Once the enclosure is stored, remove all items from the trampoline mat (bed). Make sure the mat (bed) is clean and that it has no tears or holes.

CARE AND MAINTENANCE FOR ENCLOSURE AND TRAMPOLINE

To avoid damage to the enclosure or trampoline, do not allow pets or animals inside the enclosure.

Appropriate shoes should be worn when inside the enclosure to reduce wear to the mat (bed). Follow the trampoline manufacturer's recommendations.

Prolonged exposure to the sun, especially ultraviolet rays, will shorten the life of the enclosure fabric. For longer fabric life, store the enclosure when it's not being used. A dry enclosure, properly stored, will provide the longest life of fabric, sewing, and hardware. Remove the enclosure from the trampoline during inclement weather or during lengthy periods of non-use.


SPECIAL CONSIDERATIONS

Wind

High winds could overturn trampoline and blow down the enclosure. Take down the enclosure netting and stake the trampoline in high or gusty winds.

If you anticipate high winds, move the trampoline and enclosure to a sheltered location. Disassemble the enclosure netting, and tie the round outside portion (the top frame) of the trampoline to the ground using rope and stakes. Use at least 3 tie-downs. Do not simply secure the legs to the ground, because they can pull out of the frame sockets. The enclosure only attaches to the trampoline.

See page 22 for details on the Jumping Tie Down Kit




Three point tie-down using rope and tent stakes.

MOVING the TRAMPOLINE (and ATTACHED ENCLOSURE) a SHORT DISTANCE

The enclosure poles/clamps will hold the leg assemblies together. The trampoline should be **kept horizontal and lifted slightly to move**. Disassemble the trampoline and enclosure for any other kind of movement.

Parts Drawing for JKFR14, JKFR12 **F N R 6**

Trampoline Enclosure System



ITEM	Drawing Reference Number	Quantity Required	Part Number	
			JKFR14	JKFR12
Netting and attached hardware	1	1	JKFR14N	JKFR12N
Plain pole	2	8	JKFRPP	
Swedged pole	3	8	JKFRSP	
Suspension cord	4	16	JKFRCORD	
Snap clip	5	16	030384	
Foam sleeves - blue	6	8	JKFRFSB	
Foam sleeves - green	7	8	JKFRFSG	
Hardware set - 3/8"-16 nut, 3/8" split washer, 3/8" washer, 3/8- 1 3/4" bolt	8	1 bag	JKFRHS	** 32 flat washers
Cap nut	8	8		
Top clamp assembly	9	8	JKFRTC	
Bottom clamp	10	8	JKFRBC	
Pole cap - blue	11	4	JKFRPCB	
Pole cap - green	12	4	JKFRPCG	
Sewing needle tool	13	1	JKFRSN	
Rope sections	14	8	JKFRRS	
Warning placard	15	1	080762	
Frame/pole warning labels	16	4,2 (6 total)	080703,080704	

