




PAD FRAME ASSEMBLY

(FOR USE ON 12/14/15FT ROUND TRAMPOLINE FRAMES)

LAY THE FRAME PAD OVER THE FRAME OF THE TRAMPOLINE

Lay the Frame Pad on the frame. Adjust the position of the Frame Pad so the notches are aligned with the trampoline legs as shown. **If your trampoline is a JUMPPOD** style with the enclosure frame inserting directly into the T-connectors, be sure the four (14ft) or five (15ft) enclosure frame openings are aligned to the holes in the four (14ft) or five (15ft) Large T-Sockets. (See picture below, LEFT)



ATTACH THE FRAME PAD TO THE FRAME USING THE ATTACHED STRAPS



Once the frame pad is laid in the correct position on the frame, there will be up to two types of straps to secure the pad. Begin at a starting location next to a T-Connector and circle the frame in a clockwise position (see Location #1, ABOVE) and be sure to attach every strap.

See the pictures below for the types of straps and their attachment directions.



ELASTIC CLIPS

These attachments are located on the outer ring of the frame pad and should be crossed over the the top rail frame and then hooked into the V-Ring closest to them.



ELASTIC TIE DOWN

These attachments are on the inner ring of the frame pad and should be tied into the v-ring closest to them.